

Building a Commercial Deck

A grid system held up by adjustable supports simplifies construction of this rooftop deck

by Jerry Bannister

y company builds a lot of decks for hotels, condo complexes, and restaurants in the Seattle area. These decks are often located on roofs, which presents a number of challenges. For one, we must make sure we don't damage the surface of the built-up roof system during construction. Another tricky part of building a deck on top of a commercial building is that a BUR roof surface often slopes in multiple directions, making it difficult to produce a level finished product above it. To address both problems, lately we've been using adjustable pedestals instead of our traditional method-4x4 or 4x6 sleepers ripped to the slope of the roof-to support our deck framing.

Pedestal systems are available from a few manufacturers; on the project shown

in this article, we used Bison's Versadjust adjustable pedestals. Pedestals can be used with conventional deck framing, but here we used them to support modular 4-by-4-foot grids that we framed off site with pressure-treated 2x4s. Pedestals are also often used to support wood tiles and large-format concrete pavers.

Bison Pedestals

Bison makes both fixed and adjustableheight pedestals, along with adapters and installation accessories for different types of deck surfaces. The Versadjust pedestals we used here are made of highdensity polypropylene and have a weight capacity of up to 1,250 pounds. Their design features an adjustable screw thread that allows them to be set to a predetermined height (**Figure 1**); they come in four different sizes, ranging from the V-1 (with a height range from 2¹/4 inches to 2³/4 inches) to the V-4 (with a height range from 5³/4 inches to 9³/4 inches). Extensions are available to increase the height of a pedestal assembly to up to 24 inches, though bracing, available from the manufacturer (bisonip.com), must be added to the assembly.

Versadjust pedestals also have an adjustable slope. Rotating the bottom can adjust the slope up to 5 degrees, which is useful on some of the roofs that we work on. At the top of the pedestal, a four-way tab automatically spaces the grids or tiles while preventing them from moving around. Screw-in anchors are available that can be used to lock certain wood tiles in place after installation (the anchors aren't required for heavier stone or concrete pavers). If maintenance is necessary, the anchors can be unscrewed, allowing individual tiles to be removed from the pedestals for access to the roof deck underneath.

The trick with any pedestal system is accurately estimating the number of pedestals that will be needed. Bison offers plenty of layout and planning help, though an engineer may be required to calculate roof loads and determine that a structure is capable of supporting the pedestals in their proposed positions.

Grid System

When we're working on top of a commercial roof, we need to carefully control and monitor weight distribution so that we don't damage the roof during construction. On this job, we preassembled 4-by-4-foot grids, which we framed with pressure-treated 2x4s and finished with Trex Transcends decking (in the "treehouse" color) installed with hidden fasteners. Each of the assembled grids weighed about 100 pounds, making them fairly easy to handle.

We needed to build about 150 grids to cover the more than 2,400 square feet





Figure 1. Bison Versadjust pedestals (A) were used to support the large-format stone pavers on this sloped access ramp (B, C). The adjustable pedestals can also support conventional wood framing, as well as the 4x4 grids shown in this article.

Building a Commercial Deck





Figure 2. To avoid damage to the roofing, the author's crew prefabricated modular 4-by-4-foot deck grids on the ground, stacked them on pallets, and lifted them up to the rooftop with a crane.

Figure 3. Once installed on top of the pedestals, the grids were fastened together with long structural screws.

of deck that the project called for, so we saved a lot of time by constructing the grids production-style in our shop. After trucking the prefab grids to the jobsite, we stacked them 15 high on pallets, and strapped them together so that we could lift them onto the rooftop using a crane (**Figure 2**). Each pallet weighed about 1,500 pounds, so we were careful to evenly distribute them across the roof. From there, it was simply a matter of placing each grid on the adjustable supports, with each corner of the grid supported by a pedestal.

Layout. Working from a square layout that we snapped on the roofing, we marked the location of the supports using a can of white marker paint. Using our trusty ZipLevel (see "A Tougher Jobsite Level," page 30), we checked the rough height at each support location to determine which size pedestal would be needed. Then we dialed in the rough height of each support by spinning it up or down. Later, as we set the grids, we fine-tuned the heights so that our deck surface was perfectly flat.

Installation. On most of our commercial jobs the roofing is completed before we arrive on site, with the base sheet and torch down ready for us to place the pedestals. The pedestals aren't fastened to the roof structure, but are just held in place by the weight of the deck, so the roof system doesn't require any additional waterproofing. Still, there are a few extra steps that we take.

When we cut any PT framing, we carefully seal all exposed ends with Copper-Green Brown Wood preservative (coppergreen.com), a 10% copper naphthenate solution. In addition, we take care not to leave joist hangers, screws, or any other metal products that could damage the roofing surface in contact with it. As we work, we carefully sweep or blow debris out from below the installed deck to keep the understructure clean. Finally, we protect the roofing by placing each pedestal on top of a 5-inch-diameter rubber mat.

Once our grids were installed on top of the pedestals and leveled, we screwed them all together with structural screws. Using long bits, we drove the screws through the gaps in the decking (**Figure 3**). Then we installed Trex 1x8 and 1x12 fascia around the perimeter to help lock the panels together. The weight of the deck is sufficient to resist typical wind uplift loads in this area.

Rails

Usually our rail systems are mounted independently of the roof system. However, on the job shown here, steel stanchions had been installed before the roof was torched down. Later, powder-coated aluminum rail *continued on page 30*

Building a Commercial Deck



Figure 4. The pedestal-supported deck grids wrap around a 120-square-foot bocce court. Steel stanchions for the railing system (to the right of the deck) were installed before the torch-down roofing.



Figure 5. With the aluminum railing sections slipped down over the stanchions, the deck is nearing completion. Yet to be installed is the fascia, which will wrap around the entire deck to box it in.

continued from page 26

posts were slipped down over the stanchions (**Figure 5**).

In other cases, we lag-bolt 4x4 PT posts to the deck frame—which we beef up around the perimeter with 4x4 and 4x6 blocking—and then install post sleeves. If we're using surface-mounted posts that are lag-screwed in place, we reinforce the deck frame underneath with PT 4x6 blocking laid flat and securely fastened to the substructure.

Cost

The cost to build a rooftop deck using Bison supports varies depending on the type of framing, the size of the finish decking material or grid, and the height off the rooftop. For example, on a different project, we installed an access ramp composed of 2-by-2-foot Kronos pavers, thereby increasing the number of Bison supports needed as well as the cost per foot. In addition, support pedestals are sometimes required in areas other than at the corners, depending on the layout and loads. On this project, the cost to support the 4x4 grid system worked out to less than \$2 per square foot of deck area. *

Jerry Bannister owns BHD Construction, in Seattle, Wash.

A Tougher Jobsite Level

Laser levels take a beating on our jobsites and frequently end up in the repair shop. For a tougher alternative, my Seattle-based survey-supply house steered us toward a ZipLevel Pro-2000 (ziplevel.com), a high-precision altimeter that works a little like a water level.

The controls are contained in the measurement module, a small square box connected to the base unit with a 100-foot cord. To use the level, I set my benchmark elevation by compressing and holding the module's "zero" button. Once the benchmark is established, the ZipLevel can be used to transfer that elevation (plus or minus $\frac{1}{16}$ inch) wherever the box is placed, which can be anywhere within a 200-foot radius of the base unit.

With the ZipLevel, we can go around corners and get into nooks and crannies that would be out of sight for a laser. And while I was concerned at first about dragging around a 100-foot line on top of a BUR roof, we've found that the line is extremely tough and that abrasion has not been an issue. *—J.B.*

